



Container with active shipment Opticooler - most important handling items

1. When leaving a Warehouse Battery capacity Temperature program is running	min. 95% (P1/P2/P3)
--	------------------------

2. Transport

Trucking (upon loading onto a truck*) Battery capacity Temperature program is running Reefer truck temperature* = <small>*(We recommend a reefer truck)</small>	min. 95% (P1/P2/P3) Container Set Temperature
--	---

Flight (upon loading on aircraft) Battery capacity Temperature program is running	min. 70% (P1/P2/P3)
--	------------------------

3. Arrival (Destination/Hub/etc.)

Plug in container **immediately** after arrival

4. Final Destination

Switch off container **only** if the goods have been removed
Charge container up to 100%